

Mission

The Microbiology subproject is the source of environmental and microbiological expertise that determines the stress response pathways that will be studied, helps the computation group verify the stress response pathway models, develops engineered strains of *Desulfovibrio vulgaris*, establishes the phenotype and culture conditions most appropriate for the engineered strains, verifies stress response as it relates to metal and radiomide reduction, and produces the large quantities of biomass needed for protein complex characterization and imaging by the other groups

Environmental Stress

The environment is the context in which genomes evolved, function, and continue to evolve. It is the only context in which they can be fully understood.


Stressors and Stress Response Pathways

- DOE Relevant Environmental Stress Response Pathways in DVH studied by VIMSS to date: O₂, NO₃, NO₂, pH (5.5, 10), NaCl, KCl, Cr, Heat & Cold shock, Growth Phase
- Planned FY06
 - DVH mutants repeat with previous stresses, DP4
 - DVH stress with Cr, U reduction

Producing Engineered Strains with Tagged Proteins

- Genetics for Project
- Tag proteins for complex isolation
- Tag proteins for imaging
- Create deletion strains

Bar-coding




Functional Characterization of the *S. cerevisiae* Genome by Gene Deletion and Parallel Analysis, (1999) Winzler et al., SCIENCE VOL 285 4 AUGUST 9 1991


Tag Proteins for Imaging

The SNAP-Tag™ Technology


Reaction of SNAP-tag (gold) with para-substituted benzyl guanine, leading to covalent attachment of a label (green) to the protein of interest (blue).



covalys




Stress Response in Bacteria




Tag proteins for Complex Isolation

Features of Strip-tag from IBA



Tagging procedure currently used for *D. vulgaris*



Quality Control on Tagged Protein Constructs

Sequence PCR construct both orientations

Single colony isolation of *D. vulgaris* transformants


PCR testing of *D. vulgaris* transformants

Southern analysis of *D. vulgaris* transformants

Unique pattern to distinguish from parent


Unique pattern to distinguish from plasmid

Deletion Strains




Mutagenic cassette

Transform *Desulfovibrio vulgaris*




Tandem affinity tags for better purification: STF

STF: Strip-tag, TEV, and 3xFLAG



Creation of the Host *D. vulgaris* Strain for Unmarked Deletion Constructions



D. vulgaris JW710 was born!

Current Progress in Deletion Construction

Deletion	Protein annotation	Mutant
Δfur	Global regulator, iron uptake	JW707
$\Delta perR$	Global regulator, oxidation	JW708
Δzar	Global regulator, zinc uptake	JW709
Δupp	UPTase	JW710
$\Delta norM1$	Na ⁺ -dependent, multi-drug anti-porter pump	JW400
$\Delta DVU0164$	cation diffusion facilitator	JW401
$\Delta nhaC-1$	Na ⁺ /H ⁺ antiporter	JW382
$\Delta nhaC-2$	Na ⁺ /H ⁺ antiporter	JW383
$\Delta nhaD$	Na ⁺ /H ⁺ antiporter	JW381
$\Delta mnhA$	Na ⁺ /H ⁺ antiporter (Ech hydrogenase, subunit EchA)	JW380
Δung	Uracil N-glycosylase	JW386

Phenotyping of Tagged Strains


Phenotypic Microarray™ analysis is a recently developed analytical tool to understand the phenotype of an organism. This technique can be useful to understand the growth changes of an organism when changing medium, temperature, or adding a stressor, or when testing mutant strains. The plates, which are commercially available from Biolog™ (Hayward, CA), consist of an array of 20 plates. In our laboratory, we have developed the ability to use these plates under anaerobic conditions and are able to culture an obligate anaerobe, *Desulfovibrio vulgaris* successfully by inoculating the plate in an anaerobic chamber. The plates are then host sealed in polyethylene bags containing an anaerobic sachet. It was found that preconditioning of the cells in specialized media was required for the different types of plates in order to get a valid phenotype. The plates have been successfully used to characterize the phenotype of the *D. vulgaris* Hildenborough ATCC 29579 and are currently being applied to mutant strains to provide rapid screening of mutant phenotypic changes, for rapid pathway analyses and modeling. See <http://www.biolog.com> for sample data sets and analyses.

Optimization of Growth Conditions and Scale-up

Culturing large quantities of biomass with the exact characteristics needed for the best characterization by the other subprojects will require a large number of growth curve studies and analysis at different time points using different techniques. In addition to classical techniques using measurements of direct microscopic cell counts, optical density, total protein concentrations, MPN, etc., we will automate and increase throughput by using the automated growth curves with the Omnilog phenotypic arrayer described above and using real-time analysis of cells under different conditions using synchrotron infrared microspectroscopy. The Omnilog will allow us to screen more than 24 growth conditions on each 96-well plate. Since each well in each plate can be read every few minutes and 50 plates can be handled simultaneously, this will allow us to screen 1200 growth conditions in 80 h and more than 2400 every week. This will enable us quickly to find the optimal growth characteristics for each tagged and wildtype strain of interest. The optimal conditions will then be scaled up in 1 liter batch cultures and then in 1 liter chemostats and finally in 3 liter or 7 liter full-scale chemostats. Though this technique works well and has been used by the VIMSS project for the past 2 years it does not provide critical information on the best time for sampling for desired proteins or cell changes to maximize recovery of the target proteins that. The synchrotron infrared microspectroscopy provides real-time analyses that will characterize the physiological states of cells and to optimize harvesting times.

Large-Scale Biomass Production and Harvesting

Biomass Production with Turbidostats



Summary

During the first 3 months, the MS has supplied the EM project with several sets of DVH on biofilms for analysis, three 5-liters of DVH biomass for water-soluble protein complex purification studies, and 120 l of DVH biomass for membrane protein complex purification. We started using tandem affinity tagging of proteins using three distinct tags in order to purify the protein of interest for detailed characterization. The first uses a "Strip-tag" that inserts a streptavidin binding peptide easy enrichment and we have currently constructed 16 such tags. However, in order to attain even higher protein enrichment, we are assessing the proven approach of a CTF (a.k.a. SPA) tag that includes a calmodulin binding protein (CBP), a protease (tobacco etch virus) and a 3 x FLAG site for monoclonal antibody binding versus an "STF" tag that replaces CBP with a streptavidin binding peptide. At issue is the hypothesis that since the latter is only 8 amino acids compared to 125 with CBP, it should be less likely to interfere with localization/orientation of the protein within the cell. All three approaches are currently being assessed with DscC (DVU2776), a protein in the dissimilatory sulfite reductase pathway that is essential for cell growth via sulfate respiration. Once we have confidently determined the best approach, we intend to tag at least 60 selected proteins in the coming year. Twenty of these proteins will also be tagged with a peptide including a tetracycline motif that allows in situ imaging. Since the chemistry upon which this tag is based is thiol chemistry, we must first establish that the sulfate generated by these bacteria does not irreversibly interfere. FtsZ (DVU2499), a cell division protein, is the first candidate for testing the efficacy of this procedure. Within the time scope of this project, we intend to differentially tag >300 of the gene products in *D. vulgaris*. This information is expected lead to a more thorough understanding of not only the proteins involved in metal-reduction but also their protein-protein interactions and characterization of the complete pathway(s) for these activities.

ACKNOWLEDGEMENTS

PCAP is supported by the U. S. Department of Energy, Office of Science, Office of Biological and Environmental Research, Genomics Program-GTL through contract DE-AC03-76SF00098 between Lawrence Berkeley National Laboratory and the U. S. Department of Energy.